



## Moomba Compression Facility

### Receipt and Delivery Points

#### Receipt Points

| Name                            | Location  | Pressure (kPa)                   | Physical Capacity (GJ/Day)<br>[see note 1] | Zone<br>[see note 2] |
|---------------------------------|---|----------------------------------|--|----------------------|
| Moomba Low Pressure Trade Point | A virtual point, located in the suction (low pressure) header within APA's Moomba Compound. | Minimum: 6,000<br>Maximum: 6,500 | 360,000                                    | MCF-RZ-01            |

#### Delivery Points

| Name                             | Location   | Pressure (kPa)                     | Physical Capacity (GJ/Day)<br>[see note 1] | Temperature (°C) | Zone<br>[see note 2] |
|----------------------------------|--|------------------------------------|--|------------------|----------------------|
| Moomba High Pressure Trade Point | A virtual point, located in the suction (high pressure) header within APA's Moomba Compound. | Minimum: 10,000<br>Maximum: 14,920 | 360,000                                    | 0 - 60           | MCF-DZ-01            |

Note 1: Hourly Physical Capacity unless otherwise stated is the Physical Capacity at the point divided by 24 and multiplied by the MHQ Factor for the Facility as set out in Schedule 10 of the Facility Specific Terms.



## **Moomba Compression Facility**

### **Receipt and Delivery Points**

Note 2: Zones descriptions are accurate as at January 2019, however are subject to change in accordance with the National Gas Rules. The zone information published in the AEMO Transportation Service Point Register prevails in the event of an inconsistency.